

# INSTALLING THE SUPER SWIM UNIT

To install the in-deck base in concrete is easy.

## STEP ONE:

Locate the exact location for Super Swim by measuring and marking the station or stations. (See location instruction sheet)

## STEP TWO:

Drill the 1" hole 4" deep using a 1" concrete drill bit. (NOTE: The use of a Hammer Drill works best)

## STEP THREE:

Clean the hole and surrounding area with a wet cloth, removing all the drilling powder. Fit the base into the hole to make sure it goes all the way in. The oval plate should be flush with the deck.

## STEP FOUR:

Now mix the Metal Crete with water in a small cup or bowl. Mix about 3/4 of the metal Crete with water until it has the consistency of thick gravy. Pour the grout into the hole about 1/3 way full. Press the base into the hole. Let the grout set 2-3 hours before using. If the pool is in use, cover the base with a damp towel. Clean up any excess grout with a wet cloth.

