

NEW POOL INSTALLATION

For new pool installation, first follow the location instructions.

- Once you have determined where you are going to install the Super Swim base in the pool deck, and you are ready to pour, place a 1" P.V.C. sleeve 4" long into the spot where you want the base installed.
- Place the P.V.C. sleeve in the wet concrete deck, taking care that it is flush with the deck and straight up and down.
- Tape the end of the P.V.C. sleeve so it will remain clean inside. This will provide a receptacle for the base.
- After everything is finished and inspected with the final deck finish applied, you are ready to concrete the base in place.

The Super swim base comes with its own hydraulic concrete pack called Metal Crete.

- Mix according to the directions on the bag. It should be mixed to the consistency of thick gravy.
- Be sure the base goes all the way into the P.V.C. sleeve so the face is flush with the deck.
- Remove the base and fill the sleeve about half full with the Metal Crete gravy mixture. Now press the base into the P.V.C. sleeve, allowing the Metal Crete "gravy" to ooze out around the edges of the base plate.
- Now wipe the excess Metal Crete off the base and deck with your finger, then with a damp cloth.
- Let set for one (1) hour.

